




Portable heater Oil filled radiator - Operating instructions




PRODUCT DESCRIPTION HEATER – OIL FILLED RADIATOR:


- 1 – Handle
- 2 – Power Switch
- 3 – Thermostat Control
- 4 – 24 Hour Timer
- 5 – Cord Storage
- 6 – End Cap
- 7 – Metal Axle Wheels



Power Switch



Thermosat



Timer Control

CAUTION: SURFACE IS HOT IN OPERATION

This Portable heater should not be operated unless it is placed in an **UPRIGHT** position. **REMOVE ALL PACKAGING MATERIAL FROM HEATER**

OPERATION:

- 1) Select an indoor location for the portable radiator away from electrical cords, curtain drapes and other furnishings. DO NOT place heater directly beneath an electrical outlet or against paper board or low density fibreboard.
- 2) Push MODE switch to OFF and turn the thermostat to LOW before plugging in the oil filled radiator
- 3) Connect heater electric cord plug into suitable 230V AC electrical outlet then push MODE switch to ON
- 4) Switch the heater to one of the three power settings

I for 1000W
II for 1500W
I+II for 2500W



****Each power switch lights up when activated****

- 5) The operating temperature is selected by adjustment of the thermostat. The hottest setting will be when the thermostat is to 'HIGH', the coolest when it is set to 'LOW'
- 6) To determine the correct working temperature for your conditions turn the thermostat to 'MAX' position. The power light will be activated and the radiator will start to get warm. When the unit reaches the required temperature, slowly turn the thermostat anticlockwise until the power light goes out. The temperature will now be kept constant.
- 7) The first time the heater is used there may be an odour that will disappear after the first 30 minutes of operation. The odour is due to a lubricant used in the manufacturing of the heater
- 8) The heater should be serviced by qualified personnel or returned to the manufacturer for servicing

ANTIFREEZE FUNCTION – Turn the unit on and put the thermostat on the antifreeze position. When the ambient temperature drops to 0c, this function will maintain the room temperature at about 5c.

24 Hour Programmable Timer

1. The timer operates when the slide switch is in the TIMER position ▽
2. To set the timer, rotate the clock dial clockwise, until the current time is aligned with the indicator arrow at the centre
3. For times when you wish the heater to switch on, push the corresponding time segment towards the centre. Each segment represents around 20 minutes, so if you want the heater continuously on for 2 hours, push 6 segments toward the centre face
4. NOTE: The dial turns CLOCKWISE ONLY. Forcing the clock face in the other direction will destroy timing gear. The timer will stop functioning when unplugged or during a power failure. The correct time must be reset when power is restored

IMPORTANT SAFETY INSTRUCTIONS

When using any electrically powered product, basic safety precautions should always be followed, including the following:

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT.

WARNING – to reduce the risk of fire, electrical shock or injury to persons or property:

1. The surfaces of this oil filled radiator heater are hot whilst in operation. Always allow a cool-down period before moving it to another location
2. Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating unattended
3. Always unplug the heater when not in use
4. Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to the authorized service facility for examination, electrical or mechanical adjustment, or repair
5. Do not use outdoors
6. This heater is not intended for use in wet or damp locations. Never locate heater where it may fall into a bathtub or other water container
7. Do not run cord under carpeting. Do not cover cord with throw rugs, runners. Arrange cord away from traffic area and where it will not be tripped over
8. To disconnect heater, turn switches to off position, then remove plug from outlet. Pull only by the plug. Do not pull on the cord when disconnecting it
9. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause electric shock or fire, or damage the heater
10. To prevent a possible fire, do not block air intakes or exhaust in any manner
11. Do not use in areas where gasoline, paint, or flammable liquids are used or stored
12. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons
13. Avoid the use of an extension cord because the extension cord may overheat and cause a risk of fire

14. This heater is filled with a precise quantity of special oil. Repairs or if there are any leakages whether the portable heater is purchased or on hire must be reported immediately to London Cool on 0800 440444.

London Cool air conditioner and heater rental and sales

This document has been compiled in good faith, but no representation is made or warranty given (either express or implied) as to the completeness or accuracy of this information